

There are four Firmware versions for your model, based on the Serial Number and your region's power grid. Installing the incorrect version can cause your projector to stop functioning.

If the leading digit of the last five numbers is a 0, download firmware build N.

If the leading digit of the last five numbers is a 9, download firmware build P.

Once you have determined whether your projector requires the N or P style of firmware, you must then select which the version that matches your region's AC power specifications. If you are unsure about your region's AC power specifications, please see "[Electricity Around the World](#)" at [Kropla.com: Help For Travelers!](#)"